



For assistance,
please call 2513 2513.

ApeosPort®-VI C7771 / C6671 / C5571 / C4471 / C3371 / C3370 / C2271
DocuCentre-VI C7771 / C6671 / C5571 / C4471 / C3371 / C3370 / C2271



No. and Component

- 1) <Services Home> button
- 2) <Job Status> button
- 3) <Power Saver> button
- 4) <Interrupt> button
- 5) <Clear All> button
- 6) <Stop> button
- 7) <Start> button
- 8) <C> (Clear) button

Enquiry

Scan QR Code for more instruction.




Visit below website for more online support.
<https://support-fb.fujifilm.com>

Copy




At [Copy] menu, select copy features. Press <Start> button.




Click [2 Sided Copying]. Make a 2 sided output from both 1 sided original or 2 sided original.

Fax



Dial fax numbers using the Control Panel. Select the features. Press <Start> button.




Click [Address Book]. Select recipient(s). Press <Start> button.

Scan to PC




Select the destination to store the data in. Click [Close] to finish.




Select Scan features. Press <Start> button.

Email



Select a recipient from the address list. Click [Close] to finish.



Select Scan features. Press <Start> button.